

Float R	2008 Model	IFP Setting	IFP mm	IFP PSI
816-76-090	08 [1.500 Bore, 7.500, 1.750]	2,250	57,15	300
816-76-910	08 [1.500 Bore, 5.500, 1.000]	1,400	35,56	300
816-76-920	08 [1.500 Bore, 6.000, 1.250]	1,600	40,64	300
816-76-930	08 [1.500 Bore, 6.500, 1.500]	1,900	48,26	300
816-76-940	08 [1.500 Bore, 7.250, 1.750]	2,400	60,96	300
816-76-950	08 [1.500 Bore, 7.500, 2.000]	2,250	57,15	300
816-76-960	08 [1.500 Bore, 7.875, 2.000]	2,250	57,15	300
816-76-970	08 [1.500 Bore, 7.875, 2.250]	2,100	53,34	300
RP23	2008 Model	IFP Setting		IFP PSI
816-78-000	08, FLOAT RP23 [5.50, 1.00, 2.3 CR]	1,40	35,56	400
816-78-010	08, FLOAT RP23 [6.00, 1.25, 2.7 CR]	1,60	40,64	400
816-78-020	08, FLOAT RP23 [6.50, 1.50, 3.0 CR, CF, RM]	1,90	48,26	400
816-78-021	08, FLOAT RP23 [6.50, 1.50, 3.0 CR, CF, RL]	1,90	48,26	400
816-78-030	08, FLOAT RP23, CF, RM [7.25, 1.75, 2.9 CR]	2,10	53,34	400
816-78-040	08, FLOAT RP23 [7.50, 2.00, 3.6 CR, CF, RM]	2,25	57,15	400
816-78-041	08, FLOAT RP23 [7.50, 2.00, 3.6 CR, CF, RL]	2,25	57,15	400
816-78-050	08, FLOAT RP23 [7.875, 2.00, 3.1 CR, CF, RM]	3,25	82,55	400
816-78-051	08, FLOAT RP23 [7.875, 2.00, 3.1 CR, CF, RL]	3,25	82,55	400
816-78-060	08, FLOAT RP23 XV [6.50, 1.50, 2.4 CR]	1,90	48,26	400
816-78-070	08, FLOAT RP23 XV [7.50, 2.00, 2.8 CR, CL, RL]	2,25	57,15	400
816-78-071	08, FLOAT RP23 XV [7.50, 2.00, 2.8 CR]	2,25	57,15	400
816-78-080	08, FLOAT RP23 XV [7.875, 2.00, 2.5 CR]	3,25	82,55	400
816-78-081	08, FLOAT RP23 XV Light R [7.875, 2.00, 2.5 CR]	3,25	82,55	400
816-78-090	08, FLOAT RP23 XV [7.875, 2.25, 3.0 CR, CF, RM]	2,40	60,96	400
816-78-100	08, FLOAT RP23 XV [7.875, 2.25, 2.5 CR]	2,40	60,96	400
816-78-110	08, FLOAT RP23 XV [8.50, 2.50, 2.9 CR]	2,65	67,31	400
816-78-111	08, FLOAT RP23 XV [8.50, 2.50, 2.9 CR, CF, RL]	2,65	67,31	400
816-78-120	08, FLOAT RP23 [7.50, 1.75] w/ Vol. & Trav. Spacer	2,25	57,15	400
816-78-130	08, FLOAT RP23 Enduro [7.50, 1.75]	2,25	57,15	400
DHX AIR 5.0	2008 Model	IFP Setting		IFP PSI
816-73-090	08 DHX Air 5.0 QA [7.50, 2.00, 3.9 CR]	TBD		TBD
816-73-081	08 DHX Air 5.0 QA XV [7.50, 2.00, 2.9 CR]	1,250	31,75	200,000
816-73-090	08 DHX Air 5.0 QA [7.875, 2.00, 3.4 CR]	1,250	31,75	200,000
816-73-091	08 DHX Air 5.0 QA XV [7.875, 2.00, 2.7 CR]	1,250	31,75	135,000
816-73-100	08 DHX Air 5.0 QA XV [7.875, 2.25, 3.2 CR]	1,300	33,02	200,000
816-73-101	08 DHX Air 5.0 QA XV [7.875, 2.25, 2.6 CR]	TBD		TBD
816-73-106	08 DHX Air 5.0 QA XV GAV [7.875, 2.25, 3.2 CR]	TBD		TBD
816-73-107	08 DHX Air 5.0 QA XV [7.875, 2.25, 3.2 CR]	1,300	33,02	200,000
816-73-110	08 DHX Air 5.0 XV [8.50, 2.50, 3.1 CR]	TBD		TBD
816-73-113	08 DHX Air 5.0 QA XV [8.50, 2.50, 3.1 CR]	1,350	34,29	200,000
816-73-120	08 DHX Air 5.0 XV [8.75, 2.50, 3.1 CR]	TBD		TBD
816-73-123	08 DHX Air 5.0 QA XV [8.75, 2.50, 3.1 CR]	1,350	34,29	135,000
816-73-130	08 DHX Air 5.0 XV [9.00, 2.75, 3.3 CR]	TBD		TBD
816-73-133	08 DHX Air 5.0 QA XV [9.00, 2.75, 3.3 CR]	TBD		TBD
816-73-140	08 DHX Air 5.0 XV [9.50, 3.00, 3.4 CR]	TBD		TBD
816-73-143	08 DHX Air 5.0 QA XV [9.50, 3.00, 3.4 CR]	1,475	37,465	135,000