

⚠WARNING**BEFORE EACH USE CHECK EACH OF THE FOLLOWING:**

- Break wear / operation
 - Spoke tension
 - Rim wear / damage / trueness
 - Tires / Pressure / Sealant Retention
- Always check your disc brake rotors or caliper brake pads for excessive wear before you ride as well as the operation of the brake levers and cables.
 - Before any ride, always check your spoke tension. See [Section 3 Maintenance and Repair](#), below.
 - Always check your rims for any wear, dents, gouges and damage and that the wheels are true before you ride. If there is any damage to your rims, replace them BEFORE you ride.
 - Always check your tires for tire bead and tire sidewall fraying or damage. If either is damaged, see [WARNING at Section 3\(a\)](#). Additionally, check tire pressure and ensure that tires are within the specified range on the tire's sidewall. Visually inspect the tire's sidewall to ensure the bead is appropriately and evenly seated around the circumference of the rim on both sides. For WTB TCS rims and WTB TCS tires, take note and ensure that no sealant is seeping from the tire's sidewall. Any signs of seepage or sealant can and may be indicative of a damaged tire and require replacement before riding.

